

Applicable interface: cement mortar surfaces, gypsum boards, concrete surfaces

Steps	Apply material	Add water ratio	Apply method	Coverage(one time)	Remark
1	Penetrant primer 18KG	/	Rolling/Praying	180-216㎡	
Construction interval	12-24h				
2	Same color primer 22KG	15-20%	Rolling/Praying	176-220㎡	
Construction interval	2~4h(20-25℃)				
3	Same color primer 22KG	15-20%	Rolling/Praying	176-220㎡	
Construction interval	Over 24h(20-25℃)				
4	Stone granite paint 20KG	/	Spraying	12-16㎡	After it's produced, if it's left for a long time, the material might be a bit thick or slightly separated, gently stir with a wooden stick (do not use a high-speed electric mixer for stirring), you can add 3-5% water appropriately. Use a dedicated spray gun for spraying, with a caliber of 3.0-4.0.
Construction interval	12~24h(20-25℃)				
5	Stone granite paint 20KG	/	Spraying	12-16㎡	After it's produced, if it's left for a long time, the material might be a bit thick or slightly separated, gently stir with a wooden stick (do not use a high-speed electric mixer for stirring), you can add 3-5% water appropriately. Use a dedicated spray gun for spraying, with a caliber of 3.0-4.0.
Construction interval	24-48h				
Polish	Use 240#-320# sand paper				
6	Exterior Topcoat18KG	15-20%	Rolling	180-216㎡	
Construction interval	4-6h				
7	Exterior Topcoat18KG	15-20%	Rolling	180-216㎡	
Dry time	48h fully cured				