

Applicable interface: cement mortar surfaces, gypsum boards, concrete surfaces

Steps	Apply material	Add water ratio	Apply method	Coverage(one time)	Remark
1	Penetrant primer18KG	/	Rolling/Praying	180-216㎡	
Construction interval	3~5h				
2	same color primer22KG	20-25%	Rolling/Praying	176-220㎡	
Construction interval	3~5h				
3	same color primer22KG	20-25%	Rolling/Praying	176-220㎡	
Construction interval	4-6h				
4	Granite paint20KG	/	Spraying	14-20㎡	After it's produced, if it's left for a long time, the material might be a bit thick or slightly separated, gently stir with a wooden stick (do not use a high-speed electric mixer for stirring), you can add 3-5% water appropriately. Use a dedicated spray gun for spraying, with a caliber of 3.0–4.0.
Construction interval	6~8h				
5	Granite paint20KG	/	Spraying	14-20㎡	After it's produced, if it's left for a long time, the material might be a bit thick or slightly separated, gently stir with a wooden stick (do not use a high-speed electric mixer for stirring), you can add 3-5% water appropriately. Use a dedicated spray gun for spraying, with a caliber of 3.0–4.0.
Construction interval	24-48h				
Polish	Use 240#-320# sand paper				
6	Exterior Topcoat18KG	15-20%	Rolling	180-216㎡	
Construction interval	4-6h				
7	Exterior Topcoat18KG	15-20%	Rolling	180-216㎡	
Dry time	48h fully cured				