

Applicable substrates: suitable for interior walls. Cement surfaces, cement-based surfaces, substrates fully coated with putty powder, reinforced concrete surfaces, and red brick surfaces.

Steps	Apply material	Add water ratio	Apply method	Coverage(one time)	Remark
1	Universal Penetrate primer 18KG	0-10%	Rolling	220m ²	To address different substrate conditions, you can choose to apply either Universal Penetrate primer or Interior White primer by roller.
Construction interval	4-6h				
2	Universal Penetrate primer 18KG	0-10%	Rolling	220m ²	To address different substrate conditions, you can choose to apply either Universal Penetrate primer or Interior White primer by roller.
Construction interval	8-12h				
3	Lime Powder 1kg	Dry powder:water = 1:1.5 - 2 kg	Brushing	12-16m ²	1. Adjust the water addition ratio according to the air temperature and the absorbency of the substrate. 2. After mixing, allow to stand for 15 minutes, then filter through a 100-mesh screen before brush application. 3. When semi-dry, lightly sweep with a brush to reduce brush marks. 4. For this inorganic product, the color will become lighter when applied at low temperatures; normally at 25°C and above, the color will be deeper.
Construction interval	6-8h				
4	Lime Powder 1kg	Dry powder:water = 1:1.5 - 2 kg	Brushing	12-16m ²	When semi-dry, lightly sweep with a brush to reduce brush marks.
Construction interval	8-12h				
Polish	Use 600-grit sandpaper to polish and remove dust.				
5	Interior seamless topcoat 18kg	10-15%	Rolling	220m ²	
Construction interval	4-6h				
6	Interior seamless topcoat 18kg	10-15%	Rolling	220m ²	
Dry time	>24h				