

Applicable space: Suitable for indoor large walls, interior living room walls and other home spaces, or commercial indoor spaces.						
Steps	Apply material	Add water ratio	Apply method	Tool	Coverage(one time)	Remark
1	Anti-alkali Sand Primer 22KG	20-25%	Rolling	Short wool roller	65-90m ²	Using a short-nap roller, apply a small amount of material evenly to the surface to be coated, ensuring complete coverage.
Construction interval	Standard room temperature:4-6h(20-25 °C) Summer :2-4h(30-35 °C) Winter:12-24h(5-10 °C)					
2	Anti-alkali Sand Primer 22KG	20-25%	Rolling	Short wool roller	65-90m ²	Using a short-nap roller, apply a small amount of material evenly to the surface to be coated, ensuring complete coverage.
Construction interval	Standard room temperature:8-10h(20-25 °C) Summer :6-8h(30-35 °C) Winter:12-24h(5-10 °C)					
3	Velourfin 5KG	20-25%	Rubbing	Block sponge	60-80m ²	Wet the sponge with water, wring it dry, and then apply the material. Apply the material unevenly in a circular motion, with a natural transition
Construction interval	Standard room temperature:8-10h(20-25 °C) Summer :6-8h(30-35 °C) Winter:12-24h(5-10 °C)					
4	Velourfin 5KG	20-25%	Rubbing	Block sponge	60-80m ²	Wet the sponge with water, wring it dry, and then apply the material. Apply the material unevenly in a circular motion, with a natural transition
Dry time	Standard room temperature (20-25 °C): 24h, fully cured for 7 days					