Suitable for: Interior walls and ceilings. It is seamless, making it easy to clean and maintain.

Steps	Apply material	Add water ratio	Apply method	Tool	Coverage(one time)	Remark
1	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling	Wool roller	130-180㎡ / 270㎡	When applying to absorbent substrates, use Penetrate primer.
Construction interval	8-12h (25℃)					
2	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling	Wool roller	130-180㎡ / 270㎡	When applying to absorbent substrates, use Penetrate primer.
Construction interval	Over 24h (25℃)					
3	Loulan Paint20KG+Pigment	7-8kg	Trowelling	Stainless steel screwdriver	18-22㎡	
Construction interval	24h (25℃)					
Polish	240# sand paper					
4	Loulan Paint20KG+Pigment	7-8kg	Trowelling	Stainless steel screwdriver+ Scrubbing roller	18-22㎡	1. Apply the trowel while using a textured roller to create the desired texture. 2. When the trowel is semi-dry, use it to pat and create the texture again. When it is surface dry, use it to smooth and flatten the surface.
Construction interval	24-48h (25℃)					
Polish	240# sand paper					
5	Interior Seamless topcoat 18KG	15-20%	Rolling/Spraying	Wool roller	210-250㎡	
Construction interval	6-8h (25℃)					
6	Interior Seamless topcoat 18KG	15-20%	Rolling/Spraying	Wool roller	210-250㎡	
Dry time	24h (25℃)					