Applicable area: Suitable for interior walls

Steps	Apply material	Add water ratio	Apply method	Coverage(one time)	Remark
1	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling/Spraying	65-90㎡ / 220-270㎡	
Construction interval	8-12h				
2	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling/Spraying	130-180㎡ / 220-270㎡	
Construction interval	over 24h				
3	Plaster Base 20KG + pigment	1:0.3-0.35	Trowelling	35-40㎡	Leveling
Construction interval	12-24h				
4	Bianco Carrara 25KG	3-5%	Trowelling	7-9㎡	After leveling, use a batch knife to tap the surface, pull up the honeycomb texture, and after half drying, press it down
Construction interval	over24h				
polish	Polish with 80 grit sandpaper to remove dust				
5	Interior Seamless topcoat 18KG	15-20%	Rolling	210-250㎡	
Construction interval	8-12h				
6	Interior Seamless topcoat 18KG	15-20%	Rolling	210-250㎡	
Construction interval	Completely dry within 24 hours				