Suitable for: Interior walls.

Steps	Apply material	Add water ratio	Apply method	Coverage(one time)	Remark
1	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling/Spraying	130-180㎡ / 220-270㎡	
Construction interval	8-12h				
2	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling/Spraying	130-180㎡ / 220-270㎡	
Construction interval	Over 24h				
3	Lime Stone Ⅱ 25kg	2-3%	Scraping	14-16㎡	When mixing, use a putty mixer (avoid using a toothed dispersing disc). You may add 2–3% clean water to dilute the material before adding pigment, then mix. The mixing time should be controlled within 5 minutes; avoid over-mixing.
Construction interval	12-24h				
Polish	Use 80-# sandpaper to sand or scrape away any hard-to-reach areas until smooth, then remove the dust.				
4	Lime Stone Ⅱ 25kg	2-3%	Scraping	14-16㎡	Irregular flat application, flattening
Construction interval	24-48h				
Polish	First, use 80-# sandpaper to smooth it out, then use 180-#, and finally 320-# sandpaper.				
5	Interior Seamless topcoat 18KG	15-20%	Rolling	210-250㎡	
Construction interval	8-12h				
6	Interior Seamless topcoat 18KG	15-20%	Rolling	210-250㎡	
Dry time	24h fully cured				
Polish	Lightly sand with 1000-grit sandpaper				