Applicable space: Suitable for interior/exterior walls

Steps	Apply material	Add water ratio	Apply method	Coverage(one time)	Remark
1	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling	130-180㎡ / 220-270㎡	
Construction interval	8-12h				
2	Anti-alkali Sand Primer 22KG / Interior White Pirmer 22KG	20-25%	Rolling	130-180㎡ / 220-270㎡	
Construction interval	Over 24h				
3	Straw paint-medium18kg+emulsion1.5kg	5kg	Trowelling	20-24㎡	First, mix and stir 80% of the water and the added emulsion according to the mixing ratio (main material: nano liquid: water = 18kg: 1.5kg: 5kg) until even. Then add it to the medium straw main material and stir for about 3-5 minutes. After making sure it's uniform, add the remaining 20% of water and continue stirring for 3-5 minutes.
Construction interval	24-48h				
4	Straw paint-medium18kg+emulsion1.5kg	5kg	Trowelling	20-24㎡	First, mix and stir 80% of the water and the added emulsion according to the mixing ratio (main material: nano liquid: water = 18kg: 1.5kg: 5kg) until even. Then add it to the medium straw main material and stir for about 3-5 minutes. After making sure it's uniform, add the remaining 20% of water and continue stirring for 3-5 minutes.
Construction interval	24-48h				
Polish	Use from 320#-600# sand paper to polish by steps				
5	Matte topcoat18kg	15-20%	Rolling	210-250㎡	
Construction interval	12-24h				
6	Matte topcoat18kg	15-20%	Rolling	210-250㎡	
Dry time	24h fully cured				